



Liste des pièces

Code pièces	Désignation
CH49671210	EMBASE 1210
CH49681210	COTE 1210
CH33631210	FOND FIXE 1210
CH49691210	AVALOIR INFERIEUR 1210
CH151231210	AVALOIR SUPERIEUR 0 200 /1210
CH600991210	DEFLECTEUR 1210
CH103061210	CHENET 1210
CH101601210	PLAQUE DECOR 1210
CH102121210	DEMI GRILLE FOYER 1210
CH102631210	GRILLE COMPLEMENT 1210
CH121011210	FACADE 1210
CH128611210	PORTE FOYER 1210
CH62050841210	REGISTRE REGLAGE AIR 1210
CH25583178	POIGNEE FUSEAU
CH128781210	POIGNEE PORTE FOYER 1210
CH133161210	CENDRIER 1210
CH43771210	VIS EPAULEE 1210
CH186901210	VITRE 60,5 X 39 1210
CH30211210	CLAME VITRE 1210
CH188163164	JOINT 0 8
CH38593163	MAIN FROIDE FIL D ACIER
CH1000333170	MAIN FROIDE EN FONTE
CH103451210	OBTURATEUR DROIT 1210
CH103441210	OBTURATEUR GAUCHE 1210